





Flite Seating System Power Arm Wiring Instructions




Step 1




- Feed both cables through holes in beam.
- Ensure Female end is left to connect to Male end on Arm.
- Ensure Grommet is in place in beam hole.
- Cables should come out the end of the beam with a slot cut out.

Step 2



- Attach arm to beam.
- Connect the 2 protruding cables ends together using the white connector.
Attach the cable with plug to the spare end of the connector.

Step 3



- Push connector into beam cavity.
- Locate the cable with plug into the slot on the end of beam.
- Attach end plate with countersunk machine screw.

Contact Us

Our head office is located in central London where we manage global sales, design & production.

OMK Design Ltd.
30 Gresse Street
London, W1T 1QR
United Kingdom

enquiries@omkdesign.com

+44 (0)207 631 1335

