





Seville with Arms Assembly Instructions




General Information



1. Beam
2. Beam End Cap
3. M8 x 30mm CSK Machine Screw
4. Seat End Cap
5. Arm

6. Seat Extrusion
7. 45mm Nylon Spacer
8. M8 x 25mm CSK Machine Screw
9. 20mm Nylon Wedge

Step 1: Fix beam end cap to beam




- Attach 1 x beam end cap to beam using 1 x M8 x 30mm CSK machine screw.

Parts Required:

- 1 x Beam
- 1 x Beam End Cap
- 1 x M8 x 30 CSK Machine Screw


Step 2: Fix seat end cap to seat sections



- *Locate seat end cap to each end of seat extrusion.*
- *Push to fit firmly.*


Note: Seat end caps are left and right handed.

Step 3: Attach initial seat sections



- Slide 2 x seat extrusions onto the beam and push them down until they are at the beam end cap.

Step 4: Insert nylon wedges




- Lock seat extrusion in place using 4 x 20mm nylon wedges (2 per side).
- Lock wedges in groove under seat sections using correct tools.

Note: Make sure to space wedges evenly along beam.

Parts Required:

4 x 20mm Nylon Wedges

Step 5: Fit nylon spacers




- Slide 2 x 45mm nylon spacers onto the beam until they meet the seat extrusions.
- Insert 2 x M8 x 25mm CSK machine screws into arm holes.
- Slide 2 x 45mm nylon spacers onto the beam until they meet the screw.

Parts Required:


4 x 45mm Nylon Spacer
2 x M8 x 25mm CSK Machine Screw

Step 6: Fit additional seat extrusions



- Repeat steps 3, 4, and 5, until reaching the end of the beam.

Step 7: Attach beam end cap




- *Attach 1 x beam end cap to beam using 1 x M8 x 30mm CSK machine screw.*

Parts Required:

1 x Beam End Cap
1 x M8 x 30mm CSK Machine Screw

Step 8A: Attach wall mounted brackets




- *Attach each wall mounted bracket using 3 x M8 x 30 button head machine screws.*

Parts Required [per leg]:

1 x Wall Mounted Bracket
3 x M8 x 30 Button Head Machine Screw

Step 8B: Attach freestanding legs




- *Attach each freestanding leg using 3 x M8 x 30 button head machine screws.*

Parts Required [per leg]:

1 x Freestanding Leg
3 x M8 x 30mm Button Head Machine Screw

Step 8C: Attach floor fixed legs




- *Attach each floor fixed leg using 3 x M8 x 30 button head machine screws.*

Parts Required [per leg assembly]:

- 1 x Floor Fixed Leg
- 3 x M8 x 30mm Button Head Machine Screw

Step 9: Attach arms



- *Unscrew the M8 x 25mm CSK machine screws from between the nylon spacers.*
- *Locate arms between the seat sections and attach using 2 x M8 x 25mm CSK machine screws.*

Parts Required [per arm]:

1 x Arm
2 x M8 x 25mm CSK Machine Screws

Contact Us

Our head office is located in central London where we manage global sales, design & production.

OMK Design Ltd.
30 Gresse Street
London, W1T 1QR
United Kingdom

enquiries@omkdesign.com

+44 (0)207 631 1335

